


SANYO

Casement Type
Air-Conditioner

Coolish Living
Comes Easy Now!



Main Features:

High Efficiency • Fuzzy Logic (Advance Microcomputer Control For Human Comfort)
• Night-Set Back • Timer • 1 Hour On/Off • 4 Fan Speed • Auto Sweep
Drainless • Using 13 Amp Power Point • Easy Installation

SPECIFICATION - SANYO CASEMENT TYPE AIR CONDITIONER

MODEL		SAC-88G
Frequency	Hz	50
PERFORMANCE		
Cooling Capacity	kw	1.9
Air Circulation (High)	M ³ /h	260
Moisture Removal	Litre/h	1
ELECTRICAL RATINGS		
Phase		Single
Voltage Rating V		230
Running amps	amp	4
Power Input	w	880
C.O.P	w/w	2.16
FEATURES		
Air deflection:		
Horizontal		Automatic
Vertical		Manual
Air Filter		Washable
Automatic temperature control		Thermostat
Timer		12 hr Off Timer 1 hr On/Off Timer
Fan Speeds		
Compressor		Rotary
Refrigerant		R-22
DIMENSIONS & WEIGHT		
Height	mm	755
Width	mm	345
Depth	mm	198
Net Weight	kg	25



✓ Specifications & data subject to change without notice
 ✓ ISO 9002 certification
 ✓ 35°C DB/24°C WB outdoor air temperature & 27°C DB/19°C WB indoor air temperature



- 1 Transmitter**
To send signal to control the airconditioner
- 2 Room Temperature Sensor**
To detect room temperature in order to function normally
- 3 Display Indicator**
To indicate various function of the airconditioner
- 4 Function Button**
It is an operation mode to allow selection of cooling, dehumidify or heating mode according to the required temperature.
- 5 Sleep Button**
Press the 'Sleep' button during the cooling operation and 'Sleep' will appear on the left bottom of the display indicator.
The microcomputer in the system will adjust the room temperature automatically a little higher or lower for saving of electric power.
- 6 Timer Button**
This button indicates the setting time and the remaining time in timer. It is also a selector for automatic ON or OFF of the air conditioner.
- 7 Fan Speed Button**
This is a function for airflow adjusting .
The availability to control airflow pattern on "slow", "medium", "high" or : "automatic".
- 8 Temperature Button**
▲ button allows room setting temperature to rise.
▼ button allows room setting temperature to drop.
- 9 Power Button**
To access on switching the airconditioner power ON/OFF. Turns On when pressed once and turns OFF when pressed again.
- 10 1 Hour Auto OFF Button**
A: in case of ON state, in spite of the setting at "Timer" state, once this button is pressed, air conditioner will stop functioning after 1-hour.
B: In case of OFF state, once this button is pressed, air conditioner will start to operate automatically and will stop after 1-hour.
- 11 Flap Button**
It controls the left/right air direction. The louvre angle of vertical direction can be adjusted and it serves as sweeping to left/right. (Exclusively for universal louvre use and for model without a universal louvre, it is not necessary).



Distributed By:



SANYO Singapore Pte. Ltd.
 No. 1 Toh Tuck Link Singapore 596222
 Tel: (65) 6336 0066 Fax: (65) 6338 0518